


WIRING SCHEMATIC



Legend

- Line Voltage
- Low Voltage
- - - Optional
- Compressor Overload
- Run Capacitor
- Temperature Sensor
- Wire Ground
- Open on rise thermostat
- Heater
- Transformer
- C Common
- S Start
- R Run

UNLESS OTHERWISE SPECIFIED
 TOLERANCES:
 .X ± .060" .XX ± .030"
 .XXX ± .015"
 FRACT ± 1/16" ANG ± 1/2°



INDUSTRIAL COOLING EQUIPMENT
 141 WILSON AVENUE
 GREENSBURG, PA 15601
 724-837-2204 * 1-888-967-8234
 FAX 724-837-3386

SCHEMATIC X		REV
DATE 02-20-08	DWG NO	REV
SHEET 1 OF 2	IQ200208-A	2

REVISIONS

REV	DESCRIPTION	DATE	CHECKED
1	Alrm output, heat, fan cycling	4/12/2007	SJP
2	Change cool relay contacts	6/29/09	SJP